









EcoFlow accessories

Protective cover (A, B)

▶ Protective cover to shield the EcoFlow guide profile when loading the conveyor track. Select cover for border outside (BG = 0) or border inside (BG = 1)

Material: steel; galvanized

Scope of delivery: 2 protective covers; includes fastening material

Brake (C)

▶ Brake for gently bringing containers to a stop

Material: steel; galvanized

Corner pieces (D)

- ► Corner pieces for self-assembly of workpiece pallets
- ► For isolating parts from the pallet queue, well-defined guidance and stopping surfaces, good transition through curves and avoidance of edges where trapping may occur

Material: PA; ESD

Scope of delivery: 4 corner pieces; includes fastening material

Flexible bridge (E)

- ► Flexible bridge for easy material supply in the flow rack system. The container is stopped by a rail holder with stop and is moved manually to the inclined position
 - $-a_{max} = 40^{\circ}$ (tubular cross tie)
 - a_{max} = 30° (double tubular cross tie)

Material: steel; galvanized

Scope of delivery: includes fastening material

	r die	ESD	No.
A Protective covers – outside slide rail (BG = 0)	Set		3 842 537 583
B Protective covers – inside slide rail (BG = 1)	Set		3 842 537 584
C Brake	20		3 842 537 740
D Corner pieces for workpiece pallets	Set	(3 842 536 054
E Flexible bridge	20		3 842 537 950